# Unit Tests performed on the models

## DriverSwRequest:

- Enable button: This unit test checks if the reqMode changes to reqMode. Cruise when the enable button is pressed.
- o Set button: This unit test checks if the reqMode changes to reqMode.Set when the Set button is pressed.
- Disable button: This unit test checks if the reqMode changes to reqMode.Disabled when the disabled button is pressed.
- Resume button: This unit test checks if the reqMode changes to reqMode.resRequest when the cruise control system is reengaged.
- Increment Button Short: This unit test checks if the reqMode changes to reqMode.inc\_short when the "Inc" button is pressed.
- Increment Button Hold: This unit test checks if the reqMode changes to reqMode.inc\_Long when the "Inc" button is held for more than 500 milli seconds.
- Decrement Button Short: This unit test checks if the reqMode changes to reqMode.dec\_short when the "Dec" button is pressed.
- Decrement Button Hold: This unit test checks if the reqMode changes to reqMode.dec\_Long when the "Dec" button is held for more than 500 milli seconds.

#### • CruiseControlMode Mode:

- KeyPosition: This unit test checks if Key is inserted when the Driver requests to engage the Cruise Control System.
- DriveMode: This unit test checks if the mode is in Drive when the Driver requests to engage the Cruise Control System.
- AboveBreakThreshold: This unit test checks if the brake pressure applied by the driver is higher than 5Psi
  whether the Cruise Control system disengages.
- Vehicle Above Speed Range: This unit test checks if the Cruise Control System is not engaged when the Driver tries to engage it when the vehicle speed is above operating range.
- Vehicle Below Speed Range: This unit test checks if the Cruise Control System is not engaged when the Driver tries to engage it when the vehicle speed is below operating range.
- Increment: This unit test checks if the vehicle speed increases by 1kmph when the reqMode changes to reqMode.inc\_short
- IncrementHold: This unit test checks if the vehicle speed increases by 5kmph when the reqMode changes to reqMode.inc\_Long
- Decrement: This unit test checks if the vehicle speed increases by 1kmph when the reqMode changes to reqMode.dec\_short
- DecrementHold: This unit test checks if the vehicle speed increases by 5kmph when the reqMode changes to reqMode.dec\_Long

## • TargetSpeedThrottle Model:

- opMode.Enabled : This unit test checks if the opMode changes from opMode.Disabled to opMode.Enabled when the reqMode changes to reqMode.Cruise
- opMode.Disabled: This unit test checks if the opMode changes from opMode.Enabled or opMode.Activated to opMode.Disabled when the reqMode changes to reqMode.Cancel
- opMode.Activate: This unit test checks if the opMode changes from opMode.Enabled to opMode.Activate
  when the reqMode changes to reqMode.Set
- opMode.Increment: This unit test checks if the opMode changes from opMode.Activate to opMode.Increment
  when the reqMode changes to reqMode.inc\_Short
- opMode.Decrement: This unit test checks if the opMode changes from opMode.Activate to opMode.Decrement when the reqMode changes to reqMode.dec\_Short

### • crs\_controller:

 Functional Test: This functional test checks if the DriverSwRequest, CruiseControlMode and TargetSpeedThrottle models are functioning as expected.